

Self-adhered Flashing & Primers

Tech Support / Sales: 800-334-1676
www.tamlyn.com

Self-adhered flashings are a key component for an effective water resistant barrier system. These products are flexible, versatile and easily installed for :

- Flashing windows and doors
- Flashing wall penetrations (pipes, electrical outlets, conduits)
- Achieving a continuous air barrier systems
- Bridging gaps in construction materials
- Integrating rigid flashing materials
- Self-sealing or gasket membrane applications

When properly installed, these products effectively achieve a water tight system that keeps moisture out of critical areas. Products may come available in a variety of adhesive technologies. The technology used should be compatible with the construction materials, surface and climate conditions of the installation.

For proper adhesion, flashing must be installed on a clean, dry surface, free of contaminants and within the temperature limitations of the adhesive. They must be applied using a hard roller or hand applicator.

Construction sites can present challenges for any adhered product. Surface conditions, dips in temperature, dust and other contaminants may challenge product adhesion and limit the application window. The use of primers is a common practice for enhanced adhesion and to overcome most challenging conditions. Primers are used for :

1. Challenging substrates (concrete, glass matt faced gypsum, porous surfaces...)
2. Extending the installation temperature window
3. Weathered or oxidized surfaces
4. Any time adhesion challenges are observed

Tamlyn® Flashing system primer recommendations

The following primers have shown enhanced adhesion with Tamlyn® flashing products and are readily available through most home improvement stores and specialty dealers:

1. **3M - HS 90 Spray Adhesive**
2. **MFM - Low VOC Spray Adhesive**
3. **Eternabond - EternaPrime Spray Primer and Surface Conditioner**
4. **Loctite - Professional Performance 300 Spray Adhesive**
5. **Sta-Put SP80 Spray Adhesive**
6. **ProtectoWrap Protecto-Tak Spray Adhesive**

It is the responsibility of the installer to review product restrictions and verify suitability for the application. Installer must test primers prior to installation to ensure compatibility with all materials used.

For additional information or guidance, contact Tamlyn® at 800 334-1676

